



Wind rose diagram for station 15010. The diagram shows wind frequency by direction and speed. The most frequent wind direction is North (N) at 12.81%, followed by North-Northwest (NNW) at 10.54%, and North-Northeast (NNE) at 9.72%. The least frequent is Calm at 2.25%.

Direction	Frequency (%)
N	12.81
NE	7.13
E	7.12
SE	16.88
S	15.54
SW	14.98
W	14.44
NW	9.05
Calm	2.25

KOMPLEXNÝ VÝKRES PRIESTOROVÉHO USPORIADANIA A FUNKČNÉHO VYUŽÍVANIA ÚZEMIA

[illegible]

ING. ARCH. SÁČAT	INVESTOR	
0609 AA	OBEC KÁTOV 906 49	
A K C I A	NÁVRH	DOKUMENT UPD
ÚZEMNÝ PLÁN OBCE KÁTOV		DÁTUM 05 / 2023
VÝKRES	KOMPLEXNÝ VÝKRES PRIESTOROVÉHO USPORIADANIA A FUNKČNÉHO VYUŽÍVANIA ÚZEMIA	ZN 2a
ING. ARCH. VLADIMÍR ŠÁČAT - AUTORIZOVANÝ ARCHITEKT KANCELÁRIA ARCHITEKTÚRNEJ A INŽENIERSKÉJ SLUŽBY KANCELÁRIA - V.P. TOŤKA 30, 906 01 SENICA		
